

Please follow these instructions when using the Grills

1 Turn the Gas Timer to 1 hour

CFF
11 F Magnit
1C21


2 Turn the Pilot Light Control On



- 3 Open the Burner Ignition Door and light the Pilot
- 4 Turn the Burner of Choice on



Please Remember to TURN OFF the Gas Timer,
Pilot Control
Ignition Door Lock Code: 148 and Burners



Enjoy Your Meal

